

KINETIC NEOGRIP BOOT FOOT (FELT)

Item No
H135

Waders Size Chart

Choosing the right size is the key for optimal comfort and performance. The right fit must be snug but not too tight. Too tight fit can cause stretching of the seams and result in leakage.

The sizes are available in Standard. An average built person's starting point is the Standard size.

To give you an indication of your size, follow the measurements shown in the tables below, using the 6 measuring points being Waist, Hip, Thigh, Inseam, Outseam and Sock inside length. This will give you a fairly good idea about the size you need, but trying the waders at your local retailer is always recommended.

KINETIC WADERS SIZE CHART

Standard	38-39	40-41	42-43	44-45	46-47
Chest cm	94	101,5	111,5	116,5	122
Hip cm	99	106,5	116,5	122	127
Thigh cm	66	68,5	70	74	74,5
Inseam cm	78,5	81,5	89	94	96,5
Outseam cm	129,5	134,5	144,5	149,5	152
Boot inside length cm	26,5	27,5	28,5	30,5	31

